



Impedance Standard Substrate









(Pitch: 75-150 um, Configuration: GSG)

P/N: 104-783, S/N: SB110166.12




104-783B



 <div>Thru</div> <div>Short</div>	<div>Thru delay: 1 ps</div> <div>Impedance: Nominally 50 Ω</div> <div>Recommended Overtravel: ACP 75 – 125 μm Infinity 50 – 75 μm</div>	 <div>Load</div> <div>Precision 50 Ω Load</div>	<div>For optimum calibration accuracy only the Red -marked load standards should be used</div> <div>DC accuracy: +/- 0.3 %</div> <div>Note: Ensure the bias supply is turned off during calibration. Applying bias to the probe during calibration could cause the resistance of the load to change</div>	<div>Verification Lines</div> <div><div>Thru Delay 3 ps; Length 446 μm</div></div> <div><div>Thru Delay 7 ps; Length 896 μm</div></div> <div><div>Thru Delay 14 ps; Length 1796 μm</div></div> <div><div>Thru Delay 27 ps; Length 3496 μm</div></div> <div><div>Thru Delay 40 ps; Length 5246 μm</div></div>	 <div>130 μm</div> <div>Alignment Marks</div> <div>Note: An Open is synthesized by raising the probes in air a minimum distance of 250 μm above the chuck surface</div>
---	---	--	--	--	--

All of the above specifications are based on an overtravel (downward movement of probe after initial touchdown on the substrate) of 75-125 μm. This amount of overtravel can be set before calibration on the Impedance Standard Substrate (ISS) using the alignment marks (allows precise setting of probe separation and overtravel). Figure 1 shows that initial contact with the edge of the probe tips should be made at reference plane X. The desired overtravel and thus skate (forward movement of probe tips after initial contact with substrate) is then achieved by adjusting the Z height on the positioner to move the edge of the probe tips to reference plane Y. This can also be seen from the photographic images shown in Figure 2.



Calibration Coefficients are dependent on the probe tip configuration, placement on a standard, and the standard configurations. This leads to unique calibration coefficients for a unique pair of probe and ISS. Therefore, the calibration coefficients are supplied with the probe not with the ISS.